


Using Gestures to Navigate Independently

The camera on the front of the ClassVR headset means that students can control it independently using a range of simple gestures or button presses.

Selecting Experiences

Keeping your eyes fixed on the icon you want to select, move your hand in front of the headset until you can see it at the bottom of the screen. Make a select gesture with your hand – choose from thumbs-up, pinch or okay sign – holding it about 30cm in front of the camera. The image will turn green when your gesture has been recognised.



Alternatively, tap the navigation pad on the right side of the headset.






Scrolling Round an Image or Menu

Tilt your head to pan sideways, which allows you to see in 360 degrees without turning around.



Going Back to the Menu

While wearing the headset, shake your head smoothly from side-to-side, or press the back button on the left side of the headset.



When the teacher is directing students through a playlist, the only control available to students is the ability to pan from left to right by tilting their head. Other gestures are not available, to ensure all students remain on-task.