



Sending the Headsets Back to Student-Directed Mode

If you've finished stepping your students through a Playlist and would like them to explore independently again, you can click the Home button at the bottom of the Devices pane.



This will send the headsets back to the menu or 'holodeck' view, where students can select experiences themselves from the last collection that was loaded.



You can change the content available to students by sending a Playlist from the Portal, or by scanning a QRKey on one of our ClassVR Lesson Plans.