Logging in to the ClassVR Portal

To begin using the ClassVR Portal to manage your headsets, you'll need to log in.

You should receive an email inviting you to ClassVR. If you are responsible for setting up the devices, this email will be sent to you during the setup process. Otherwise, your administrator should invite you via the portal.

Click the link in the email to activate your account.

You will need to choose a password, then complete a verification procedure.

After this, you will be directed to our End User License Agreement. If you're happy with it, scroll to the bottom of the page and click 'I agree'.

Now that you have logged in, you should see the ClassVR Portal Interface.

To access the ClassVR Portal at any time, simply visit http://portal.classvr.com.